

REPAIR™

ENGINEERED WOOD FLOOR REPAIR ADHESIVE

ESSENTIALS LINE



TECHNICAL DATA SHEET

February 2023
Version 2.0

RESIDENTIAL

MULTI-FAMILY

LIGHT COMMERCIAL

HEAVY COMMERCIAL

DESCRIPTION

Repair is a complete, professional wood floor repair system. It can be used to patch hollow spots in engineered wood flooring. Adhesive refills can be purchased separately.

APPROVED FLOORING TYPES

WOOD: Engineered Hardwood

PREPARATION INSTRUCTIONS

1. Locate hollow area(s) in the wood and outline with resealable tape (prepare all hollow areas at the same time).
2. Drill hole(s) with a 3/32" drill bit in the area(s) outlined by the tape (for larger areas, at least two holes are recommended - drill one hole on each side of the hollow spot).
3. Stir adhesive
4. Screw applicator tip onto syringe prior to filling - use one of the following options: **a.** Pour adhesive directly from bottle into syringe **b.** Place applicator tip directly into adhesive and draw into syringe.

APPLICATION INSTRUCTIONS

ONLY USE WITH ENGINEERED WOOD PRODUCTS.

1. Place the applicator tip into the hole and inject adhesive until you feel back pressure. If multiple holes were drilled, inject adhesive until it comes out the other hole(s) (repeat in other holes until hollow spots are completely filled.)
 - Do not weigh down the repaired area.
2. Plug the hole(s) by tapping a wooden dowel into them (use a dowel that is slightly oversized [1/8"] and taper one end with a knife or sandpaper for a tight fit).
3. Cut the wooden dowel off even with the floor and use a dowel punch to lower it below the surface of the flooring.
4. Putty the hole with wood filler that blends with the floor color.

PRECAUTIONARY NOTES:

- Adhesive is thin and it can drip without pressure being applied to the syringe.
- Ensure that existing flooring adhesive is fully cured prior to use.
- If a large amount of repair adhesive is used to fill a hollow spot, some cupping of the flooring may occur and should dissipate within several days.
- Protect area from traffic for 24 hours.

CLEANING INSTRUCTIONS

While product is still wet: use a damp cloth and water to remove. If product is dried: use mineral spirits, denatured alcohol, or an adhesive remover/stripper (always check compatibility on a piece of scrap flooring). Fully clean out syringe and applicator tip for future use.

STORAGE

This product should be stored at temperatures between 50-90°F (15-32°C). While this product is freeze-thaw stable, it is necessary to protect it from freezing. Freeze/thaw stable to 10°F (-12°C).

CAUTION

DO NOT take internally. If swallowed, DO NOT induce vomiting. Call a physician immediately. KEEP OUT OF REACH OF CHILDREN.

WARRANTY INFORMATION

For warranty information, call Technical Services at **706-712-5823**, visit us on the web at **www.tayloradhesives.com** or e-mail us at **tech@tayloradhesives.com**. Flooring manufacturer's and TAYLOR's written pre-installation and installation instructions must be strictly followed or the TAYLOR warranty will be void.

TAYLOR TECHNICAL SERVICES

📞 706.712.5823
📧 tech@tayloradhesives.com
📍 3343 Dug Gap Road, Dalton, GA 30721

TAYLOR™
WITH YOU EVERY STEP™